

Running Board Instructions

4090

06 - C Toyota FJ Cruiser

(No Drilling Required)

INSTALLATION PACKAGE

Running Board	2
Bracket s	6
Bolt Packs	2

Necessary Tools

Ratchet wrench with 1/2" & 13 mm socket
Combination wrench
Safety glasses

Bolt Pack Brackets

8mm x 3/4" Hex Bolt	10
5/16" Flat washer	10

Bolt Pack Running Boards

5/16" x 3/4" Hex Bolt	12
5/16" x 3/4" Serrated Flange Nut	12

STEP ONE : Determine proper bracket placement Fig A & B & C

1. There are (5) factory 8mm hole with factory bolts on the underside of the vehicle on each side were the brackets need to be placed. The front will use only (1) bolt as shown Fig A. The middle and rear bracket will use (2) bolts as shown Fig B.
2. Loosely bolt (hand tighten) brackets on using 8mm bolt Fig C
3. Place board on brackets by sliding mounting bolts in slots on underside of boards and allow bolt thread to drop through bracket slots with bracket mounted in position, slide 5/16" bolts down outside channels on underside of board so bolt stud will line up with bracket slots. Only one bolt is required to attach board to each bracket. Now install board on brackets to see if board is level.
4. Check board for levelness and snug fit to vehicle. Tighten outside brackets first then adjust inside bracket accordingly. Adjust and fully tighten all bracket.

STEP TWO : Board Installation Check.

- 1) Check all bolts to verify completed mounting and tightness. Installation is complete

